



500 KM Service

Perform road test and complete visual inspection of the vehicle, including engine and all related system, front and rear suspension, steering and brake system, transmission and drive train, various electrical components, check and adjust tension of wheel spokes, check and adjust fasteners for proper tightening, check steering column bearings, check and adjust alternator bolts, check brake fluid reservoir.

- Change Engine Oil and Filter
- Change Transmission Oil
- Change Final Drive Oil

5,000 KM Service

Perform road test and complete visual inspection of the vehicle, including engine and all related system, front and rear suspension, steering and brake system, transmission and drivetrain, various electrical components, check and adjust tension of wheel spokes, check and adjust fasteners for proper tightening, check steering column bearings, check and adjust alternator bolts, check brake fluid reservoir.

- Change engine oil and filter
- Change transmission oil
- Change final drive oil
- Inspect throttle body synchronization, update software if needed

10,000 KM Service

Perform road test and complete visual inspection of the vehicle, including engine and all related system, front, rear and sidecar suspension, steering and brake system, transmission and drive train, various electrical components, check and adjust tension of wheel spokes, check and adjust fasteners for proper tightening, check and adjust steering column bearings, check and adjust alternator bolts, perform valve clearance adjustment, perform carburetor adjustments and synchronization, access and replace engine air filter (if needed). Lubricate shafts, linkages, cables and splines. Check and adjust wheel bearings.

- Change engine oil and filter
- Change transmission oil
- Change final drive oil
- Flush brake fluid
- Replace spark plugs
- Replace engine air filter (if needed)
- Inspect throttle body synchronization, update software if needed

15,000 KM Service

Perform road test and complete visual inspection of the vehicle, including engine and all related system, sidecar alignment, front and rear suspension, steering and brake system, transmission and drive train, various electrical components, check and adjust tension of wheel spokes, check and adjust fasteners for proper tightening, check steering column bearings, check and adjust alternator bolts, check brake fluid reservoir.

- Change Engine Oil and Filter
- Change Transmission Oil
- Change Final Drive Oil
- Sidecar Alignment

30,000 KM Service

Perform road test and complete visual inspection of the vehicle, including engine and all related system, front, rear and sidecar suspension, steering and brake system, transmission and drive train, various electrical components, check and adjust tension of wheel spokes, check and adjust fasteners for proper tightening, check and adjust steering column bearings, check and adjust alternator bolts, perform valve clearance adjustment, perform throttle body adjustments and synchronization, access and clean engine air filter, perform fuel tank service. Lubricate shafts, linkages, cables and splines. Check and adjust wheel bearings. Inspect and replace brake fluid.

- Change Engine Oil and Filter
- Change Transmission Oil
- Change Final Drive Oil
- Replace Spark Plugs
- Replace Fuel Filters
- Replace Air Filter
- Replace Brake Fluid
- Sidecar Alignment
- Valve Clearance Adjustment