

Ford Extended Service Plans

| | | | |
|--|------------------------------------|----------------------------------|--|
| *RECOMMENDED PremiumCARE 1000+ COMPONENTS | ExtraCARE 113 COMPONENTS | BaseCARE 84 COMPONENTS | PowertrainCARE 29 COMPONENTS |
|--|------------------------------------|----------------------------------|--|

ENGINE

| | | | | |
|--|--|--|--|--|
| Manifold (Exhaust and Intake) | | | | |
| Manifold and Bolts | | | | |
| Oil Pan | | | | |
| Oil Pump | | | | |
| Seals and Gaskets | | | | |
| Thermostat | | | | |
| Thermostat Housing | | | | |
| Timing Chain (Gears or Belt) | | | | |
| Timing Chain Cover | | | | |
| Turbocharger/Supercharger Unit (Factory Installed) | | | | |
| Valve Covers | | | | |
| Water Pump | | | | |
| Harmonic Balancer and Bolt | | | | |
| Flywheel Ring Gear | | | | |
| Fuel Tank and Lines | | | | |
| Gas Fuel Injectors and Fuel Lines | | | | |
| Radiator | | | | |
| Radiator Fan (Clutch or Motor) | | | | |
| PCM Module | | | | |

TRANSMISSION

| | | | | |
|--|--|--|--|--|
| All Internal Parts | | | | |
| Seals and Gaskets | | | | |
| Torque Converter | | | | |
| Transfer Case (Including All Internal Parts) | | | | |
| Transmission Case | | | | |
| Governor Assembly | | | | |
| Transmission Module (External) | | | | |
| Transmission Mounts | | | | |
| Vacuum Module | | | | |
| Kickdown Linkage | | | | |
| Release Hubs and Bearings | | | | |
| Transmission Linkage | | | | |

REAR-WHEEL DRIVE

| | | | | |
|--|--|--|--|--|
| Axle Shafts | | | | |
| Drive Axle Housing (And Front Axle Housing for 4x4) Including All Internal Parts | | | | |
| Driveshaft | | | | |
| Retainers | | | | |
| Seals and Gaskets | | | | |
| Universal and Constant Velocity Joints | | | | |
| Bearings (Front and Rear) | | | | |

FRONT-WHEEL DRIVE

| | | | | |
|--|--|--|--|--|
| Axle Shafts | | | | |
| Final Drive Housing (And Rear Axle Housing for AWD) Including All Internal Parts | | | | |
| Hubs, Automatic Front Locking (Four-Wheel Drive) | | | | |
| Locking Rings (Four Wheel Drive) | | | | |
| Seals and Gaskets | | | | |
| Universal and Constant Velocity Joints | | | | |
| Bearings (Front and Rear) | | | | |

STEERING

| | | | | |
|--------------------------|--|--|--|--|
| Column Lock (Tilt Wheel) | | | | |
|--------------------------|--|--|--|--|

Ford Extended Service Plans

| | | | |
|--|------------------------------------|----------------------------------|--|
| *RECOMMENDED PremiumCARE 1000+ COMPONENTS | ExtraCARE 113 COMPONENTS | BaseCARE 84 COMPONENTS | PowertrainCARE 29 COMPONENTS |
|--|------------------------------------|----------------------------------|--|

| | | | | |
|---|--|--|--|--|
| Control Valve | | | | |
| Cooler and Lines | | | | |
| Idler Arm | | | | |
| Linkages and Couplings | | | | |
| Power Steering Pump | | | | |
| Pulley Assembly | | | | |
| Seals and Gaskets | | | | |
| Steering Gear Housing, Manual and Power (Including all Internal Parts) | | | | |
| BRAKES | | | | |
| Backing Plates | | | | |
| Brake Booster (Power) | | | | |
| Calipers | | | | |
| Combination Valve | | | | |
| Lines and Fittings | | | | |
| Master Cylinder | | | | |
| Parking Brake Linkage and Cables | | | | |
| Retainers and Clips | | | | |
| Self-Adjusters | | | | |
| Shaft (Brake Pedal) | | | | |
| Springs | | | | |
| Wheel Cylinders | | | | |
| Anti-lock Brake Module and Sensor | | | | |
| FRONT SUSPENSION | | | | |
| Ball Joints (Upper and Lower) | | | | |
| Control Arm Shafts and Bushings | | | | |
| Control Arms (Upper and Lower) | | | | |
| Kingpins and Bushings | | | | |
| MacPherson Struts | | | | |
| Spindle and Spindle Support Springs | | | | |
| Stabilizer Bar | | | | |
| Tie Rods | | | | |
| Load Leveler Suspension System | | | | |
| Roll Stability Control | | | | |
| A/C and HEATING | | | | |
| A/C Clutch | | | | |
| A/C Clutch Bearings | | | | |
| A/C Compressor | | | | |
| A/C Compressor Clutch Switch | | | | |
| A/C Compressor Head | | | | |
| A/C Compressor Seals | | | | |
| A/C Condenser | | | | |
| Evaporator | | | | |
| Field Coil | | | | |
| Pulley | | | | |
| A/C Accumulator | | | | |
| Automatic Temperature Control | | | | |
| Heater Blower Motor | | | | |
| Heater Core Assembly | | | | |
| Heater Control Assembly | | | | |
| Instrument Panel Registers and Air Ducts | | | | |
| ELECTRICAL | | | | |
| Ignition Switch | | | | |
| Radiator Fan Relay | | | | |
| Speedometer/Odometer (Electrical and Mechanical) | | | | |

Ford Extended Service Plans

| *RECOMMENDED PremiumCARE 1000+ COMPONENTS | ExtraCARE 113 COMPONENTS | BaseCARE 84 COMPONENTS | PowertrainCARE 29 COMPONENTS |
|---|-----------------------------|---------------------------|---------------------------------|
|---|-----------------------------|---------------------------|---------------------------------|

| | | | | |
|--|--|--|--|--|
| Starter Motor | | | | |
| Starter Motor Solenoid | | | | |
| Switches (Manually Operated Electrical) | | | | |
| Voltage Regulator | | | | |
| Wiper Motors | | | | |
| Wiring Harnesses (Excluding Spark Plug Wires) | | | | |
| Intelligent 4WD Systems | | | | |
| LED lighting or Lamp Assemblies-Interior or Exterior(Factory Installed) - coverage included only if the Lighting option is purchased | | | | |
| Mirrors (Electrical Only - Not Glass Damage or Breakage) | | | | |
| Power Running Boards | | | | |
| Rear Window Power Sunshade | | | | |
| Temperature Gauge | | | | |
| Vista Roof | | | | |
| Wiper-Activated Headlamps | | | | |

HIGH TECH

| | | | | |
|---|--|--|--|--|
| Instrument Cluster (Excluding Dash Pad) | | | | |
| Keyless Entry System (Excluding Door Handles) | | | | |
| Power Antenna | | | | |
| Power Door Locks and Retainer Clips (Excluding Door Handles) | | | | |
| Power Seat Motors | | | | |
| Power Window Motors/Regulators | | | | |
| Speed Control | | | | |
| In-Dash Garmin(TM) Voice Activated Navigation System (Factory and Dealer Installed) | | | | |
| Rain Sensing Wipers | | | | |
| Rear Console Refrigeration | | | | |
| Reverse Camera and/or Sensing System | | | | |
| Roll Stability Control | | | | |
| Securicode | | | | |
| SecuriLock(TM) Passive Anti-Theft Ignition System | | | | |
| Sensor (Alcohol) | | | | |
| SOS Post Crash Alert System | | | | |
| Stationary Elevated Ride Control | | | | |
| SYNC | | | | |

REAR SUSPENSION

| | | | | |
|-------------------------------------|--|--|--|--|
| Ball Joints (Upper and Lower) | | | | |
| Control Arm Shafts and Bushings | | | | |
| Control Arms (Upper and Lower) | | | | |
| Kingpins and Bushings | | | | |
| Linkage and Bushings | | | | |
| Load Leveler Suspension System | | | | |
| MacPherson Struts | | | | |
| Roll Stability Control | | | | |
| Spindle and Spindle Support Springs | | | | |
| Stabilizer Bar | | | | |
| Tie Rods | | | | |

EMISSIONS

| | | | | |
|--------------------------|--|--|--|--|
| Air Check Valve Assembly | | | | |
|--------------------------|--|--|--|--|

Ford Extended Service Plans

| | | | |
|--|---|---|---|
| <small>*RECOMMENDED</small> PremiumCARE <small>1000+ COMPONENTS</small> | ExtraCARE <small>113 COMPONENTS</small> | BaseCARE <small>84 COMPONENTS</small> | PowertrainCARE <small>29 COMPONENTS</small> |
|--|---|---|---|

| | | | | |
|-------------------------------------|--|--|--|--|
| Air Control Valve | | | | |
| Air Idle Vacuum Valve | | | | |
| Air Supply Valve (Hose and Tube) | | | | |
| Barometric Pressure Sensor | | | | |
| ECC Relay Assembly | | | | |
| EGA Control Valve | | | | |
| EGA Pressure Sensor | | | | |
| EGA Regulator Assembly | | | | |
| EGA Valve Adapter | | | | |
| EVAP Vapor Storage Cannister | | | | |
| Idler Air Control Valve | | | | |
| Knock Sensor | | | | |
| PCV Hose Assembly | | | | |
| PCV Valve | | | | |
| PCV Vapor Filter | | | | |
| Temperature Sensor (Engine Coolant) | | | | |
| Vacuum Restrictor | | | | |
| VAF Sensor | | | | |

AUDIO

| | | | | |
|---|--|--|--|--|
| Antenna, Radio (Base Assembly) | | | | |
| Brackets | | | | |
| Cables and Wiring | | | | |
| Cellular Phone, Receiver, Handset, Speaker Assembly and Antenna (Factory Installed) | | | | |
| Controls (Rear Seat) | | | | |
| Radio (AM, AM/FM), Speakers, Cassette Player, Digital CD Player, Graphic Equalizer, Premium Sound Amplifier (Factory Installed) | | | | |
| Rear Entertainment System (Factory Installed) | | | | |

SAFETY

| | | | | |
|--|--|--|--|--|
| Airbag Module Assembly | | | | |
| Diagnostic Module Assembly (Airbag) | | | | |
| Door Ajar Warning Switch Assembly | | | | |
| Guides, Bezels, Brackets and Supports (Safety Belts/Shoulder Straps) | | | | |
| Head Restraint Retainers and Sleeves (Safety Belt) | | | | |
| Key, SecuriLock(TM) (Microchip Encoded Key) | | | | |
| Lock Cylinder (Door) | | | | |
| Lock Lever Assembly (Tailgate) | | | | |
| Lock Lever Retainers, Clips and Brackets | | | | |
| Module (Passive Restraint) | | | | |
| Safety Belt Buckle (Front and Rear) | | | | |
| Safety Belt Motor Drive Assembly | | | | |
| Safety Belt Restraint Carrier | | | | |
| Safety Belt Retractors | | | | |
| Safety Belt Track Assembly | | | | |
| Safety Belt Warning Chime Assembly | | | | |
| Sensors (Airbag) | | | | |
| Shoulder Strap Track Assembly | | | | |
| Wiring Assembly (Airbag) | | | | |